

Portable Circular Saw

1. Operate only with instructor's permission and after you have received instruction.
2. Remove jewelry, eliminate loose clothing, and confine long hair.
3. Make sure all guards are in place and operating correctly.
4. Always use proper eye protection.
5. Make sure that telescoping guard returns automatically to cover the blade after each cut.
6. Do not set saw down until blade stops.
7. If the saw blade binds or smokes, stop cutting immediately.
8. Make sure the power cord is clear of the blade.
9. Be sure the material you are cutting is adequately supported.
10. Check the base setting for the proper depth of cut.

