

Portable Electric Drill

SAFETY SUGGESTIONS

1. Wear approved eye protection.
2. Disconnect the electric cord plug from the power outlet when changing drill bits.
3. Be sure the switch is off and the chuck key is removed before you connect the cord plug to the power source.
4. Do not use in damp or wet area.
5. Be sure the material being drilled is tightly clamped or secured.
6. Drill with a straight steady even pressure.
7. Be sure the drill bit is used and properly secured in the chuck.

